



说明书材质要求: 105g 有光铜版纸	说明书成品尺寸: 55*100mm
第一: 专色用6级防刮油墨+CMYK油墨要求: 1. PANTONE137C专色油墨(专色用6级防刮油墨); 如果自己配色,油墨配比为:酒联中黄(防刮)200g 酒联金红(防刮)225g 2. C色油墨:酒联天蓝墨 3. M色油墨:酒联金红墨 4. Y色油墨: pantone123C专色油墨 5. K色油墨:酒联黑墨	第二: 特别注意: 1. 印刷时看特请参考我司提供的实物样品颜色。不得偏色 2. 137C的专色不得参考C=0,M=55,Y=90,K=0对应的四色 色请颜色来看特印刷 Pantone 137C Black (两色印刷)
折叠方式: 风琴折 (双折)	备注:

特别注意: 此页内容不印刷

风琴折 + 对折 页面顺序

16P 页面顺序

9	10	11	封面
12	13	14	封底

1	2	3	4
5	6	7	8

20P 页面顺序

11	12	13	14	封面
15	16	17	18	封底

1	2	3	4	5
6	7	8	9	10

更改记录	新设计			更新封面货号 and 参数页货号, 删除专业款标记, 更新公司名和地址			品名修改, 尺寸更改, 内容删减		
	0323.V01	2023.3.22	Kitty	0124.V02	2024.1.8	QQY	0424.V03	2024.4.27	abby
	版本号	日期	设计师	版本号	日期	设计师	版本号	日期	设计师

INGCO

www.ingco.com

**PRODUCT
MANUAL**

CORDLESS SCREWDRIVER



CSDLI0802 CSDLI0802xy

x (blank, 1, 2, 3, 4, 5, 6, 7, 8, 9, E, S, A, M)

y (blank, -1, -2, -3, -4, -5, -6, -7, -8, -9, E, S, A, M)



GENERAL POWER TOOL SAFETY WARNINGS

⚠ WARNING Read all safety warnings, instructions, illustrations and specifications provided with this power tool. *Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.* **Save all warnings and instructions for future reference.**

The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.

1) Work area safety

- a) **Keep work area clean and well lit.** *Cluttered or dark areas invite accidents.*
- b) **Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** *Power tools create*

sparks which may ignite the dust or fumes.

- c) **Keep children and bystanders away while operating a power tool.** *Distractions can cause you to lose control.*

2) Electrical safety

- a) **Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools.** *Unmodified plugs and matching outlets will reduce risk of electric shock.*
- b) **Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators.** *There is an increased risk of electric shock if your body is earthed or grounded.*
- c) **Do not expose power tools to rain or wet conditions.** *Water entering a power tool will increase the risk of*

electric shock.

- d) **Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. *Damaged or entangled cords increase the risk of electric shock.***
- e) **When operating a power tool outdoors, use an extension cord suitable for outdoor use. *Use of a cord suitable for outdoor use reduces the risk of electric shock.***
- f) **If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply. *Use of an RCD reduces the risk of electric shock.***

3) Personal safety

- a) **Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of**

drugs, alcohol or medication. *A moment of inattention while operating power tools may result in serious personal injury.*

- b) **Use personal protective equipment.** *Always wear eye protection. Protective equipment such as a dust mask, non-skid safety shoes, hard hat or hearing protection used for appropriate conditions will reduce personal injuries.*
- c) **Prevent unintentional starting.** *Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.*
- d) **Remove any adjusting key or wrench before turning the power tool on.** *A wrench or a key left attached to a rotating part of the*

power tool may result in personal injury.

- e) **Do not overreach. Keep proper footing and balance at all times.** *This enables better control of the power tool in unexpected situations.*
- f) **Dress properly. Do not wear loose clothing or jewellery. Keep your hair and clothing away from moving parts.** *Loose clothes, jewellery or long hair can be caught in moving parts.*
- g) **If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.** *Use of dust collection can reduce dust-related hazards.*
- h) **Do not let familiarity gained from frequent use of tools allow you to become complacent and ignore tool safety principles.** *A careless action can cause severe injury within a fraction of a second.*

4) Power tool use and care

- a) **Do not force the power tool. Use the correct power tool for your application.** *The correct power tool will do the job better and safer at the rate for which it was designed.*
- b) **Do not use the power tool if the switch does not turn it on and off.** *Any power tool that cannot be controlled with the switch is dangerous and must be repaired.*
- c) **Disconnect the plug from the power source and/or remove the battery pack, if detachable, from the power tool before making any adjustments, changing accessories, or storing power tools.** *Such preventive safety measures reduce the risk of starting the power tool accidentally.*
- d) **Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power**

tool or these instructions to operate the power tool. *Power tools are dangerous in the hands of untrained users.*

- e) **Maintain power tools and accessories.** Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. *Many accidents are caused by poorly maintained power tools.*
- f) **Keep cutting tools sharp and clean.** *Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.*
- g) **Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed.** *Use of the power tool for operations*

different from those intended could result in a hazardous situation.

- h) **Keep handles and grasping surfaces dry, clean and free from oil and grease.** *Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.*

5) Battery tool use and care

- a) **Recharge only with the charger specified by the manufacturer.** *A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.*
- b) **Use power tools only with specifically designated battery packs.** *Use of any other battery packs may create a risk of injury and fire.*
- c) **When battery pack is not in use, keep it away from other metal objects, like paper clips, coins,**

keys, nails, screws or other small metal objects, that can make a connection from one terminal to another. *Shorting the battery terminals together may cause burns or a fire.*

- d) **Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help. *Liquid ejected from the battery may cause irritation or burns.***
- e) **Do not use a battery pack or tool that is damaged or modified. *Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury.***
- f) **Do not expose a battery pack or tool to fire or excessive temperature. *Exposure to fire or temperature above 130 °C may***

cause explosion.

- g) **Follow all charging instructions and do not charge the battery pack or tool outside the temperature range specified in the instructions.** *Charging improperly or at temperatures outside the specified range may damage the battery and increase the risk of fire.*

6) Service

- a) **Have your power tool serviced by a qualified repair person using only identical replacement parts.** *This will ensure that the safety of the power tool is maintained.*
- b) **Never service damaged battery packs.** *Service of battery packs should only be performed by the manufacturer or authorized service providers*

The symbols in instruction manual

	Read the instruction manual before using.
	CE conformity.
	Safety alert. Please only use the accessories supported by the manufacturer.
	Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.
	Charging the battery only below 40°C
	Always recycle batteries.

	Do not destroy battery by fire.
	Do not expose battery to water

ADDITIONAL SAFETY WARNING

1. Keep work area clean and well lit
2. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.
3. Keep children and bystanders away while operating a power tool.
4. Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools.
5. Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges and refrigerators.
6. Do not expose power tools to rain or

wet conditions.


7. Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.
8. Use personal protective equipment. Always wear eye protection.
9. Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.
10. Do not force the power tool. Use the correct power tool for your application.
11. Do not use the power tool if the switch does not turn it on and off.
12. Use power tools only with specifically designated battery packs.
13. When battery pack is not in use, keep it away from other metal

objects, like paper clips, coins, keys, nails, screws or other small metal objects, that can make a connection from one terminal to another.

INTENDED USE

The machine is equipped with 7.4V motor, which can provide a maximum torque of 6N.m. The electric screwdriver has 15+1 torque settings. You can adjust the torque according to your needs to complete the work of assembling furniture, fixing picture frames, repairing electrical appliances, etc.

SPECIFICATIONS



Components

1. Quick release chuck
2. Torque adjustment collar
3. Motion control activation trigger
4. Release button
5. Forward/Reverse trigger switch
6. Charging port (Type-c)

Technical specifications

Model No.	CSDLI0802 CSDLI0802xy x (blank, 1,2,3,4,5,6,7,8,9,E, S,A,M) y (blank, -1,-2,-3,- 4,-5,-6,-7,-8,- 9,E,S,A,M)
Voltage	8V
Hex shank	1/4"
No-load speed	220rpm
Max. torque	6N.m
Torque settings	15+1

OPERATION

Operate

Your screwdriver uses gyroscopic technology to sense your hand motion. To operate, press in the motion control activation trigger and turn

your hand in the direction that you want the screwdriver to operate.

Setting initial starting point

1. Grasp the screwdriver.
2. Press and hold in the motion control activation trigger.
3. To reset initial starting point first release the motion control activation trigger. Move tool to new position, then press and hold in the motion control activation trigger.

Operating in forward direction

1. Grasp the screwdriver.
2. Engage head of fastener with screwdriver accessory on work piece. Follow instructions for setting initial starting point.
3. Rotate your hand to the right and the screwdriver will activate in the forward direction.

Operating in reverse direction

1. Grasp the screwdriver.
2. Engage head of fastener with screwdriver accessory on work piece. Follow instructions for setting initial starting point.

3. Rotate your hand to the left and the screwdriver will activate in the reverse direction. To turn the tool off, release the motion control activation trigger.

Variable speed

1. The spindle speed is dependent upon the speed that you rotate your hand.
2. The slower you rotate your hand, the slower the screwdriver turns.
3. The faster you rotate your hand, the faster the screwdriver turns.
4. If you wish to increase the spindle speed, rotate your hand further in the same direction.
5. If you wish to decrease the spindle speed, rotate your hand back towards the initial starting point.



MADE IN CHINA 0424.V03

NEWWAY TECHNOLOGY (SUZHOU) CO., LIMITED

INGCO Global www.ingco.com No. 20 Dagang Road, Fuqiao Town, Taicang City, China