



说明书材质要求：80g 双胶纸	说明书成品尺寸：52*74mm
第一：专色+CMYK油墨要求： 1. 专色油墨：见实物色样调整 2. K色油墨：酒联墨墨	第二：特别注意： 1. 印刷时看样颜色请参考我司提供的实物样品颜色，不得偏色。 2. 322C的专色不得参考C=100,M=28,42,Y=48,29,K=21,6 对应的四色色谱颜色来看特印刷
	Pantone357C Pantone137C Black（三色印刷）
折叠方式： 风琴折（20P,7,8）	备注：

特别注意： 此页内容不印刷

风琴折+对折 页面顺序

16P 页面顺序

9	10	11	封面
12	13	14	封底

1	2	3	4
5	6	7	8

20P 页面顺序


11	12	13	14	封面
15				

1				
6				

更改记录	1. 新制作			1. 增加信息			1. 更改波长 红光波长改成 635-650nm 绿光波长改成 510-530nm		
	0124_J01	2024.01.09	SQY	0324_J02	2024.3.28	SQY	1024_J03	2024.10.11	QL
	版本号	日期	设计师	版本号	日期	设计师	版本号	日期	设计师

Jadever

SELF-LEVELING LINE LASER



JDLE1M03 JDLE2M03

**PRODUCT
MANUAL**

Original Instructions

ADDITIONAL SAFETY WARNING

LASER RADIATION

DO NOT STARE INTO BEAM

CLASS 2 CONSUMER LASER

PRODUCT

EN 50689:2021

 CAUTION!

While the product is in operation, be careful not to expose your eyes to the emitting laser beam. Exposure to a laser beam for an extended time may be hazardous to your eyes.

Glasses may be supplied in some of the laser tool kits. These are NOT certified safety glasses. These glasses are only used to enhance beam visibility in brighter environments or at greater distances

from the laser source.

⚠ WARNING!

Read the Safety Instructions and User Manual thoroughly before using this product. All users must fully understand and adhere to these instructions.

The following label/print samples are placed on the product to inform you of the laser class for your convenience and safety.

Do not stare directly into the beam, view directly with optical instruments, or set up the laser at eye level.

Do not disassemble the laser tool. There are no user-serviceable parts inside.

Do not modify the laser in any way. Modifying the tool may result in hazardous Laser Radiation Exposure.


Do not operate the laser around children or allow children to operate the laser; this may result in serious eye injury.

An exposure to a Class 2 laser beam is considered safe for a maximum of 0.25seconds. Eyelid reflexes will generally provide adequate protection.

INTENDED USE

The measuring tool is intended for determining and checking horizontal and vertical lines. The measuring device is suitable exclusively for operation in enclosed working sites.

SPECIFICATIONS



Components

1. Key board
2. Windows
3. Laser source
4. Pendulum lock
5. 1/4" Screw hole
6. Battery compartment

Technical specifications

Model No.	JDLE1M03
Laser color	red
Working range	0-15m
Levelling accuracy	$\pm 2\text{mm}@5\text{m}$
Line accuracy	$\pm 2\text{mm}@5\text{m}$
Levelling time	$\leq 3\text{s}$
Self-levelling angle	$\leq 4^\circ$
Laser type	635-650nm
Laser class	II , < 1mW
Input	3V DC (2x1.5V AA battery)

Model No.	JDLE2M03
Laser color	green
Working range	0-30m
Levelling accuracy	$\pm 2\text{mm}@5\text{m}$
Line accuracy	$\pm 2\text{mm}@5\text{m}$
Levelling time	$\leq 3\text{s}$
Self-levelling angle	$\leq 4^\circ$
Laser type	510-530nm
Laser class	II , < 1mW
Input	3V DC (2x1.5V AA battery)

OPERATION

Initial operation

Protect the measuring tool against moisture and direct sunlight.

Do not subject the measuring tool to extreme temperature or temperature variations. In case of significant temperature variations, allow the measuring tool to adjust to ambient temperature before putting it into operation.

Avoid heavy impact to or falling of the measuring tool.

Switch off the measuring tool during transportation.

Operation models

Note: Please keep the Lock switch at the "OFF" position during moving the laser level or storing it.

Self-leveling mode

Switch the pendulum lock to the "ON" position, and the laser level enters self-leveling mode, and the laser lights up.

The laser will self-leveling within $\pm 4^\circ$, and the keyboard will glow green/red at this time. If the laser is out of level, the laser will blink, and the keyboard will light yellow.

Switch the pendulum lock to the "OFF" position to turn off the laser level. Note that the laser level cannot be turned off by the button in this mode.

Manual mode

1. When the lock switch is in the "OFF" position, press the key button to enter the manual mode, and the keyboard will glow green/red.
2. The laser will be locked in this

| English

mode, which meets your alignment needs from different angles.

3. Short press the key button to power off.

MAINTENANCE&MALFUNCTIONS

- Maintain and keep the measuring tool clean at all times.
- Regularly clean the surfaces at the exit opening of the laser, and pay attention to any fluff or fibers.
- Wipe off debris using a moist and soft cloth, do not use any cleaning agents or solvents.
- Do not immerse the measuring tool in water or other fluids.
- If the laser level is unusable; it should be repaired by an authorized after-sales service. Do not open the measuring tool by yourself.
- In case of repairs, send the measuring tool packed in its protective packing.
- Store the tool in its case when not in

use. If storing for an extended time, remove batteries before storage to prevent possible damage.

- Do not dispose of this product with household waste.
- Always dispose of batteries per local code.
- Please recycle in line with local provisions for collecting and disposing of electrical and electronic waste under the WEEE Directive (Waste Electrical and Electronic Equipment Directive)



   Jadevermall
www.jadevermall.com

KEYWAY TECHNOLOGY (NANTONG) CO., LTD
No. 99, Gugang Road, Chongchuan District,
Nantong City, China
MADE IN CHINA 1024.J03

